


SKY CHEMICALS DAZZLE+ & LUSTRE GETTING STARTED

This step by step guide will help you navigate the initial set-up stages & ensure you get the best out of Dazzle+ & Lustre and leave your glasses sparkling clean.


- 1 Remove any glasses, chemicals or other such items that are in your glasswash

Ensure the wash cycle is set to the temperature of 60°C



- 2 Add Dazzle+ to your detergent tube - Do not add any rinse aid


Dazzle+ - Detergent with built in renovate:
Dazzle+ is designed to lift and remove grime, dirt and soil. The added renovating compounds allow greater cleaning efficacy



- 3 Run wash cycle


Recommendations:

Run the machine for 1-2 cycles - This will wash away any residual chemicals and debris from your previous wash cycles.




- 4 Add the rinse aid Lustre to the rinse tube, add glasses to the machine and run a test wash cycle

Lustre - Rinse aid:
The Lustre rinse aid is designed to wash off any residual chemicals off the glasses, ensuring that your glasses are clean and the quality of your beers are unaffected



- 5 After the test cycle check your glasses for any stains or marks and adjust the amount of Dazzle+ & Lustre in the machine accordingly (See section 6).



Now that your glasses are squeaky clean your glasswash machine is ready for use

- 6 Common issues & how to resolve them

White Marks on Glasses: May be caused by a build up of limescale or too much Dazzle+ being fed into the machine. Use our glasswash machine cleaner Supreme to properly clean your machine of limescale. Reduce the amount of Dazzle+ being fed into your machines

No Beer head or the beer is flat: Perhaps too much Dazzle+ or too little Lustre is being fed into the machine, reduce the amount of Dazzle+ being fed or increase the amount of Lustre being fed.

Glasses are covered in soil: Soil and dirt can be embedded in your glasswash machine, run a few more wash cycles with Dazzle+ alone, to help clean the machine.